


PIN-OUT OF MODIFIED CARD:

- 1 +V
- 2 -V
- 3 POWER SUPPLY COMMON
- 4 OUT "HI" } 1:2 OUTPUT
- 5 OUT "MID" }
- 6 OUT "LO" }
- 7 OUT "HI" } 1:1 OUTPUT
- 8 OUT "LO" }
- 9 GAIN ADJUST "HI"
- 10 GAIN ADJUST "GROUND"
- 11 MIC IN "HIGH"
- 12 NO CONNECTION
- 13 NO CONNECTION
- 14 MIC IN "LOW"
- 15 SHIELD

FRAME WIRING =
 RED = POSITIVE V+
 WHITE = NEGATIVE V-
 BLACK = P.S. COMMON



20dB
PAD

