# FAIRCHILD MIXING CARD MODEL 692MNNL

INSTRUCTION MANUAL

692MNNLIB/969

### FAIRCHILD MODEL 692 MNNL

#### INTEGRA II MIXING CARD

### GENERAL

In order to provide facility to mix up to 16 inputs into one buss conveniently and without gain loss, a new card has been designed by FAIRCHILD complementing the Integra II equipment This mixing card consists of passive mixing network followed by the amplifier making up the lost gain and also providing additional gain up to 20 db. Mixing network is bridging type with terminated input so that any input sees termination of 600 ohms. This is done for the following termination of the mixing network on the input keeps reason: the impedance of the complete circuit constant regardless of the number of input channels switched in and regardless of their impedances. This sort of mixing network permits use of single pole single throw switches to be used when delegating signal into the mixing net. There is no need for dummy load resistors to be switched in nor need to match the impedances. Any source impedance from 0-600 ohms can be safely connected into any one of the 16 inputs.

Amplifier fed from the mix network is a direct coupled amplifier, class AB, with the output circuit capable of delivering 18 dbm of power into 600 ohm load. Input impedance of the amplifier is very high while the output impedance is very low. Recommended load impedance should not be less than 150 ohms, inductive or resistive. If transformer is used on the output, it can be strapped as a step-up transformer with primary adjusted for 150 ohms and secondary for 600 ohms or higher. In this case one can obtain up to 21 dbm output. Gain of the amplifier is continuously adjustable over the range of at least 20 db by means of the feedback pot located on the PC card.

Application of the card, aside from use in ordinary mixing networks, extends to situations where one desires to monitor up to 16 channels by mixing them into single channel while preserving the separation between the channels of at least 70 db. In this case the input load resistor to the mixing inputs should be left out.

### SPECIFICATIONS

Number of inputs 16 or less (additional inputs

can be added if using 962 MXB card) feeding the 692 MNNL

amplifier input

Input impedance 600 ohms (accepts any source

impedance of 600 ohms or lower). 150K when the load resistor is

left out

Output impedance 2 ohms (recommended maximum load

150 ohms or higher, inductive or

resistive)

Interchannel

separation 70 db or better

Gain Unity or up to 25 db adjustable

Frequency response ± .5db 20-20 KHZ

Distortion THD .3% at maximum output of 18 dbm

.15% at line level output (4 dbm)

Noise 75 db below line level measured

on the wide band basis (unity

gain)

Power

requirements 24 VDC at 6 mA (ripple not to

exceed .5 VRMS)


### MOUNTING

692MNNL board can be mounted along with other Integra II cards in the FAIRCHILD 692RM card rack or individually in the 692SCH single card holder in conjunction with the 662 RM taking  $1\frac{1}{2}$  inches in the  $5\frac{1}{2}$  inch rack.

Since there are no inductive components in the 692 MNNL circuit, mounting of the card is not restricted to hum-free areas but can be used in the vicinity of comparatively strong magnetic fields.

#### **ATTACHMENTS**

Drawings A96442 & A96297



### NOTES:

UNLESS OTHERWISE SPECIFIED— ALL RESISTORS 1/4W, 10 % ALL CAPACITORS IN MFD. \*-TO BE SELECTED

692 M.N.N.L. SCHEMATIC

## INTEGRA II PC BOARD MOUNTING DIMENSIONS

